Installation Guide

Perlato Form Wall Mount Vanities


IMPORTANT


Before beginning installation, make sure that the vanity is the correct model and size and conduct a thorough inspection.


- Subtract 1³/₄" from vanity width to calculate distance from the right hanging hook outer edge to the left.
 Determine height by measuring distance from metal hooks to vanity base and adding desired distance from vanity base to floor. Mark wall appropriately.
- Separate the two hanging brackets by bending and cracking apart the included hardware. Drill mounting holes in wall and fasten wall brackets with screws.


Ensure brackets will be anchored to wall studs or reinforce wall for support.

- Remove drawers to facilitate installation process. Slide drawer forward, then gently tilt upwards and pull out completely.
- Hook vanity onto wall brackets. Mount support bracket onto wall directly under vanity base.










 Adjust metal hooks if necessary to properly level vanity and secure it to wall.




6. Attach faucet and drain to sink.




7. Connect overflow.




- 8. Spread non-acetic silicone sparingly along top rim of vanity. Position sink in place and use a cloth to wipe excess silicone.
- 9. Connect water supply and drain lines. Run faucet and check for leaks.






10. Slide drawers back onto tracks. Refer to instructions on next page if drawer front position needs adjustment.




HORIZONTAL OR VERTICAL ADJUSTMENT



ANGLE ADJUSTMENT

Lift strip covering drawer sides to expose more adjustment settings.



Rotate setting to make tilt angle adjustments.

